
Quick start MCU-V3RGB

Control unit for RGB strip (LEDs with constant voltage).

CONNECTION DIAGRAM



DESCRIPTION

Once the connections are made as in the drawing, the control unit is already operational via wire with the pre-set functions and default settings.

DEFAULT PARAMETERS

The control unit has pre-set parameters for standard operation. - memo function: disabled

- fade on: 0,5s
- fade off: 0,5s
- timer: none

These settings can be customised, see the full manual.

USE VIA RADIO


To be able to use a transmitter an association must first be made, see procedure on the back



RADIO PROGRAMMING

This procedure lets you programme compatible multifunctional or generic transmitters.

WHICH REMOTE CONTROL DO YOU WANT TO ASSOCIATE WITH THE CONTROL UNIT?



GENERIC TRANSMITTERS - MODELS AND CODES



With generic transmitters, the transmitter's control modes depend on the function associated with the key during the association procedure.

The available function for the key are:

TABLE 5.1 KEY FUNCTIONS OF THE GENERIC TRANSMITTER

POSITION OF DIP IN "STEP 1b" OF THE PROCEDURE	KEY FUNCTION	POSITION OF DIP IN "STEP 1b" OF THE PROCEDURE	KEY FUNCTION
DIP: OFF ON ON ON	Short pressure= ON / OFF Long pressure= DIMMER UP / DIMMER DOWN	DIP: ON ON OFF OFF	dimmer colour up / dimmer colour down
DIP: ON OFF ON ON	ON	DIP: OFF OFF ON OFF	Play / Stop "ciclo colore" (see paragraph 6.4)
DIP: OFF OFF ON ON	OFF	DIP: ON OFF ON OFF	Change duration of "colour cycle" (see paragraph 6.4)
DIP: ON ON ON OFF	Short pressure= changes colour Long pressure, load off= dimmer colour	DIP: ON OFF OFF OFF	Change effect of "colour cycle" (see paragraph 6.4)
	Long pressure, load on= save colour (see paragraph 6.1)	DIP: ON OFF OFF OFF	Soft Off 1h: fade off in 1h. (see paragraph 6.2)

WHICH TRANSMITTER DO YOU WANT TO PROGRAMME? MULTIFUNCTION TRANSMITTER (see models and codes on previous page) STEP 1a Position DIPs 1, 2, 3 and 4 to ON-ON-ON-ON DIP 1, 2, 3 e 4= ON ON ON ON STEP 2 Press the button on the receiver for a short time. The LED comes on and stays on. STEP 3 Make a transmission with the transmitter to be saved (see transmitter manual, paragraph entitled "transmitter programming"). The LED on the receiver flashes 3 times to signal that it has been received. STEP 4 The control unit listens for 30 seconds in case you want to add other transmitters. To immediately exit the procedure give a short pressure on the button on the receiver. The LED turns off

PROCEDURE

